MAINTENANCE INSTRUCTIONS

Page 1

TARKETT IQ TORO SC, IQ GRANIT SD & PRIMO SD



To help protect your floorcovering from varying levels of traffic and also as the first defence against the weather, we strongly recommend that barrier mats be installed at entry points to the building to limit the amount of wet and dry soiling. If maintained correctly, these barrier mats should limit the transfer of foot borne contamination and make the daily cleaning and maintenance programme even easier.

Polish or maintainers should not to be applied to the surface of Tarkett commercial homogeneous vinyl products, as the unique PUR factory applied surface treatment removes their necessity.

For commercial to heavy commercial applications mechanical maintenance is considered essential on a regular ongoing basis.

Initial Treatment

- 1. Allow at least 2 days from the completion of the installation of the floorcovering, prior to carrying out any wet cleaning.
- 2. Ensure that all trace of adhesive is removed from the surface of the floorcovering.
- 3. Sweep floor area with a soft broom or a V Sweep.
- 4. Depending on the level of site soiling after the installation is complete, it may be necessary to scrub the floor clean, prior to adopting the daily maintenance regime. Please find the following options.
 - a) Mop clean using Total Inventive Cleaning Ltd Scrubclean system with Total Inventive Cleaning Ltd SS1 Solution PH neutral detergent (Total Inventive Cleaning Ltd SS3 on heavily soiled areas and TIC Pal-O-Mine Range).
 - b) Scrub the surface of the vinyl using a contra rotating cylindrical machine, rotary scrubber or a scrubber-dryer standard speed machine fitted with a **Red Pad**.

If the flooring is laid in high risk area, such as some areas in health care applications please substitute the standard Scrubclean solution with Scrubclean Antibacterial (SS2), however if there is a risk of high infection the standard infection control agent such as Chlorclean or Actichlor should be used prior to standard cleaning.

Routine Maintenance

Non-Mechanical Method



- 1. Sweep floor area with a soft broom or V sweep.
- 2. Mop clean using Scrubclean system with SS1 neutral PH detergent, (SS3 on heavily soiled areas and Pal-O-Mine Range).

It is important to ensure that only the smallest amount of moisture is deposited onto the floorcovering when cleaning, so that the floorcovering surface will dry within 15 - 20 seconds.

Mechanical Method



- 1. Sweep floor area with a soft broom or V sweep.
- Spray apply a solution of SS1 neutral PH detergent, diluted as per the manufactures recommendation. A pump-up spray will allow for even distribution and economy of the cleaning solution. (SS3 should be used on areas that are heavily soiled or are greasy. Leave to stand for 5-10 minutes).
- 3. Scrub the surface of the vinyl using a contra rotating cylindrical machine, rotary scrubber or a scrubber-dryer standard speed machine fitted with a **Red Pad**.
- 4. Remove any excess water from the surface of the vinyl.



MAINTENANCE INSTRUCTIONS

Page 2

<u>Cleaning & Maintenance</u> of Stairs

Non-Mechanical Method



1. Sweep floor area with a soft broom or V sweep.

2. Mop clean using Scrubclean system with SS1 neutral PH detergent, (SS3 on heavily soiled areas and Pal-O-Mine Range).

It is important to ensure that only the smallest amount of moisture is deposited onto the floorcovering when cleaning, so that the floorcovering surface will dry within 15 - 20 seconds.



Contact Us | Email: safefloors@syrclean.com Tel: +44(0)1384 421215 Web: www.syrtic.com



TARKETT IQ TORO SC, IQ GRANIT SD & PRIMO SD

